



Maintenance and Care Guide

Distressed Portable Bar

- ALWAYS follow the instructions in the set up guide when assembling and disassembling the bar. (Setup guide is available for download on the product page on our website.)
- Do not leave the bar uncovered in a harsh environment and/or exposed to the elements.
- After each use, cover the bar, or break it down, clean it and store in a dry place. Storing it indoors is HIGHLY recommended when the bar is not in use. Wear and tear from the elements is not covered by the warranty.
- Keep two hands on the bar when pushing or moving it, to help with its stability. Especially when rolling it over uneven surfaces.
- A minimum of two people are needed to move the bar.

Laminate Maintenance and Care

- To clean the surface, use a damp cloth or sponge and a mild soap or detergent. Rinse thoroughly with warm water and wipe dry.
- Difficult stains such as coffee or tea can be removed using a mild household cleaner/detergent and a soft bristled brush, repeating as necessary. Windex and Formula 409 are OK to use. Acidic or abrasive cleaners can damage laminate surfaces; do not use them.
- If a stain persists, use a paste of baking soda and water and apply with a soft bristled brush. Light scrubbing for 10 to 20 strokes should remove most stains. Although baking soda is a low abrasive, excessive scrubbing or exerting too much force could damage the surface, especially if it has a gloss finish.
- Food dyes can cause permanent stains. If dye should happen to spill, wipe it up immediately with dish washing detergent or an all-purpose cleaner.
- Never place pots or dishes directly from the oven or burner on an unprotected laminate surface; such extreme heat can cause cracking or blistering. Always use a heat shield, hot pad or trivet.



LED Care & Maintenance

(Only Applicable if an LED Kit was Purchased)

- When transporting or breaking down the bar, be mindful of the LED strips. Disconnect the appropriate cables and connectors **before** beginning breakdown.
- When running your LED system, make sure the battery is not being used to power the bar while the charger is powering the battery. Use the battery or the charging cable to power the bar. Use only one power source at a time (if applicable). Having the battery charging while powering the bar will ruin the battery life.
- Do not leave your battery charged for more than 12 hours at a time (if applicable).