



Maintenance and Care Guide

Rustic Frames: Professional Bar, Standard Bar, & Compact Bar

- ALWAYS follow the instructions in the set up guide when assembling and disassembling the bar. (Set up guide is available for download on the product page on our website 24/7.)
- Do not leave bar uncovered in a harsh environment and/or exposed to the elements. **Wear and tear from the elements are not covered by the warranty.**
- When storing the bar: break it down, clean it and put on the cover. Store completely protected from the elements in a dry place. If you are by the ocean or in a humid climate, we recommend limiting the bars use to indoors only.
- A minimum of two people are required to move the Standard and Professional Bars. Be mindful of the acrylic or laminate panels and remove them from the frame of the bar if needed.
- When pushing the bar over a distance, it should not be stocked, and nothing should be stacked on top of it. When the bar is folded, push it from the back of the narrow end and not the wide side to keep from tipping the bar over.
- Keep two hands on the bar when pushing or moving it, to help with its stability. Especially when rolling it over uneven surfaces.
- In the rare chance something breaks that has a direct impact on the balance, mobility or weight distribution of the equipment, refrain from using the bar. This includes, but is not limited to, a broken or missing caster, weld, locking pin or spring latch.
- Regularly check clear coating finish for any scratches or dings which may compromise the bar's weather resistance. If you find a scratch or ding, touch of all weather clear coat should be used to cover the exposed steel.
- Make sure acrylic is cleaned and dried before being stored.
- When cleaning acrylic counters, use a microfiber cloth or soft sponge with warm water and a mild detergent. Use clean water to avoid mineral spots.
- DO NOT use any abrasive cloths.
- DO NOT use any caustic or abrasive cleaners or cleaners with ammonia



Laminate Care & Maintenance

(Only Applicable if Ordered)

- Laminated panels should be dried if they become wet. Laminated panels should also be covered/protected from direct sunlight.
- To clean the surface, use a damp cloth or sponge and a mild soap or detergent. Rinse thoroughly with warm water and wipe dry.
- Difficult stains such as coffee or tea can be removed using a mild household cleaner/detergent and a soft bristled brush, repeating as necessary. Windex and Formula 409 are OK to use. Acidic or abrasive cleaners can damage laminate surfaces; do not use them.